Setup / Usage:

1 Fill with clean tap water. Do not exceed water level shown.

SKIN BURN HAZARD. Water container must rest on a sturdy, level surface and in upright position.

Filling the steamer with hot water will greatly reduce the time to produce steam. A full container will operate for about 70 minutes.





2 Line up notch in hose receptacle **(a)** with the guide on the hose **(b)**. Insert hose and turn **clockwise** approximately 130°. Hand-tighten locking nut. **DO NOT cross-thread the locking nut.**

Connect other end of hose to the steam plate. Hand-tighten fitting onto plate.





3 Connect matching end of cord to the steamer. Plug in the power cord.

Make sure steamer is placed on a sturdy, level surface.

Once the power cord is plugged in, it will take about 12-15 minutes to produce steam. **DO NOT** leave steam plate unattended, or face down on any surfaces.





4 For best results, use a scoring tool or a putty knife and gently score the wallpaper in a crisscross pattern. The perforations will allow the steam to penetrate the wallpaper.

Once steam is flowing out of the steam plate, hold the steam plate flat against the scored wallpaper for about 10 seconds. Move the steam plate to a new section and remove the steamed section with the scraper blade.



Make sure to wear gloves and eye protection.

5 **DO NOT operate the steamer once the water container is empty.**

To refill, unplug power cord and let steamer cool for 2 minutes. **SLOWLY** remove steam hose and refill the container. Replace hose, plug in power cord and allow unit to reheat.





Storage :

1 Unplug the steamer from the power source.

Wait a minimum of 2 minutes and slowly open the hose connection.

Drain remaining water from the container. **NEVER** store the unit with water in the container.